

Important Assembly Note: All of our BBQ Shelters are designed as a modular system.

Regardless of which version you have purchased, your build will begin with the Base Unit. The specific variation you have purchased is created by adding the supplementary parts listed in the table below to this core structure.

Please check the table to identify the additional components required for your specific model.

Eclipse Range	
Product ID	Product Name
52706	The Eclipse BBQ Shelter With Full Sides 2 x Side Cladding Sets, 1 x Rear Cladding Set, 2 x Inner Shelves
52702	The Eclipse Deluxe BBQ Shelter With Full Sides 2 x Side Cladding Sets, 1 x Rear Cladding Set, 2 x Inner Shelves, 1 x Deluxe Kit
52703	The Eclipse BBQ Shelter With Single Foldout Bar Top 1 x Side Cladding Set, 1 x Rear Cladding Set, 1 x Inner Shelf, 1 x Foldout Side
52722	The Eclipse Deluxe BBQ Shelter With Single Foldout Bar Top 1 x Side Cladding Set, 1 x Rear Cladding Set, 1 x Inner Shelf, 1 x Foldout Side, 1 x Deluxe Kit
52704	The Eclipse BBQ Shelter With Dual Foldout Bar Tops 1 x Rear Cladding Set, 2 x Foldout Sides
52705	The Eclipse Deluxe BBQ Shelter With Dual Foldout Bar Tops 1 x Rear Cladding Set, 2 x Foldout Sides, 1 x Deluxe Kit
Grillhouse Range	
Product ID	Product Name
52719	The Grillhouse BBQ Shelter With Half Sides 1 x Chevron Back Kit
52698	The Grillhouse Deluxe BBQ Shelter With Half Sides 1 x Chevron Back Kit, 1 x Deluxe Kit
52689	The Grillhouse BBQ Shelter With Full Sides 1 x Chevron Back Kit, 2 x Side Cladding Sets, 2 x Inner Shelves
52690	The Grillhouse Deluxe BBQ Shelter With Full Sides 1 x Chevron Back Kit, 2 x Side Cladding Sets, 2 x Inner Shelves, 1 x Deluxe Kit
52693	The Grillhouse BBQ Shelter With One Half / One Full Side 1 x Chevron Back Kit, 1 x Side Cladding Set, 1 x Inner Shelf
52694	The Grillhouse Deluxe BBQ Shelter With One Half / One Full Side 1 x Chevron Back Kit, 1 x Side Cladding Set, 1 x Inner Shelf, 1 x Deluxe Kit

Meze Range	
Product ID	Product Name
52691	The Meze BBQ Shelter With Single Foldout Bar Top 1 x Chevron Back Kit, 1 x Side Cladding Set, 1 x Inner Shelf, 1 x Foldout Side
52692	The Meze BBQ Shelter Deluxe With Single Foldout Bar Top 1 x Chevron Back Kit, 1 x Side Cladding Set, 1 x Inner Shelf, 1 x Foldout Side, 1 x Deluxe Kit

Pavilion Range	
Product ID	Product Name
52695	The Pavilion BBQ Shelter With Single Foldout Bar Top 1 x Chevron Back Kit, 1 x Foldout Side
52696	The Pavilion Deluxe BBQ Shelter With Single Foldout Bar Top 1 x Chevron Back Kit, 1 x Foldout Side, 1 x Deluxe Kit
52720	The Pavilion BBQ Shelter With Dual Foldout Bar Tops 1 x Chevron Back Kit, 2 x Foldout Sides
52697	The Pavilion Deluxe BBQ Shelter With Dual Foldout Bar Tops 1 x Chevron Back Kit, 2 x Foldout Sides, 1 x Deluxe Kit

Vista Range	
Product ID	Product Name
52701	The Vista BBQ Shelter With Full Sides 2 x Side Cladding Sets, 2 x Inner Shelves
52707	The Vista Deluxe BBQ Shelter With Full Sides 2 x Side Cladding Sets, 2 x Inner Shelves, 1 x Deluxe Kit

Need a hand?

Thanks to the logical, modular nature of the base BBQ system and the additional extra components, we are confident you will find the assembly process straightforward and intuitive.

However, in the unlikely event that should you require any clarification or assistance at any stage, please do not hesitate to contact our support team on 0330 100 2530 or via the website Live Chat.

Component List

2 x Front Support Posts	3" x 3" C16	2100mm	(A1)
2 x Rear Support Posts	3" x 3" C16	1950mm	(A2)
2 x Roof Framing	2" x 2" C16	1660mm	(B1)
4 x Roof Rafters	2" x 2" C16	1260mm (Angle Cut)	(B2)
13 x Featheredge Roof		1800mm	(B3)
2 x Side Fascia Boards	4" x 1" PAR	1350mm (Angle Cut)	(B4)
1 x Front Fascia Board	4" x 1" PAR	1840mm	(B5)
1 x Decorative Front Piece			(B6)
4 x Cladding Frame (Sides)	2" x 2" C16	1100mm	(C1S)
18 x Cladding (Sides)	4" x 1" PAR	1200mm	(C2)
2 x Cladding Frame (Rear)	2" x 2" C16	960mm	(C1R)
8 x Cladding (Rear)	4" x 1" PAR	1660mm	(C3)
2 x Handrail (Side)	4" x 1" PAR	1200mm	(C4)
1 x Handrail (Rear)	4" x 1" PAR	1660mm	(C5)
50mm Green Screws			(FIX 1)
75mm Green Screws			(FIX 2)
100mm Screws			(FIX 3)



Recommended Tools

Drill Driver
PZ2 Driver Bit
Pilot Drill Bit
Tape Measure
Spirit Level

We recommend two people to assemble this BBQ shelter.


Step 1

To prevent splits, drill a pilot hole before driving screws

Using 2 x cladding frame pieces (**C1S**) and 9 x cladding boards (**C2**) assemble your side panels as shown below. The board at the top should fit flush with the frame piece, working down the timber with 25mm spaces in between each board.

Each board is held in place using 2x 50mm green screws (**FIX 1**) per side, per board, driven through the face of the cladding into the frame.

Repeat for both side panels.




Step 2

Next is to create the back panel, which is much the same as the two sides you have built in step one.

Using 2 x cladding frame pieces (**C1R**) and 8 x cladding boards (**C3**) assemble your rear panel as shown below. The board at the top should fit flush with the frame piece, working down the timber with 25mm spaces in between each board.

Each board is held in place using 2x 50mm green screws (**FIX 1**) per side, per board, driven through the face of the cladding into the frame.



All images are for illustration only. Please see individual item listings for actual item specifications.

To prevent splits, drill a pilot hole before driving screws


Step 3

With the three side/rear panels now built, they can be attached to the corner support posts.

Starting with the rear support posts **(A2)** place the rear panel between the two posts and screw into place using 3 x 75mm green screws **(FIX 2)**. The top of the panel should sit 965mm from the top of the corner post.

This is critically important so that later on when installing the decorative panel (if applicable) it is a snug fit with no gaps at the top which is where it will be secured in place to the underside of the roof frame.

The screws should be placed as per the diagram, one at the top, middle and bottom on each side, through the panel frame and into the side of the support posts.




Step 4

With the rear section fixed in place, both sides can be then screwed into position as per the diagram to the right.

The fixing method is the same as step 3, using 3 x 75mm green screws **(FIX 2)** one at the top, middle and bottom on each side, through the panel frame and into the side of the support posts.

We recommend first fastening the side panel to the rear support post **(A2)** before moving onto the front support posts **(A1)**.

Repeat the process on both sides.





Step 5

To prevent splits, drill a pilot hole before driving screws

Using the roof framing parts **(B1)** and **(B2)** assemble your roof frame as below.

Screw through the face of **(B1)** into the rafters / frame timbers **(B2)** using 2 x 75mm green screws **(FIX 2)** at each end.

Please Note: Due to the slight angle cuts on pieces **(B2)** the frame should not lay flat; this is to create the sloping pitch on the roof which will allow for water to run off the back.




(B2) Side Profile

Step 6

To prevent splits, drill a pilot hole before driving screws


Attach the featheredge roof boards (**B3**) to the roof frame you have just built in step 5 using 1 x 50mm green screw (**FIX1**) per board, per joist as indicated to the right.



Remember to leave a minimum of 20mm overlap on each board and to screw through the thick part of the featheredge board.

The featheredge boards should sit flush at both the front and rear but will overhang the frame at both sides by 70mm.

See below for underside view.



All images are for illustration only. Please see individual item listings for actual item specifications.

Step 7

To prevent splits, drill a pilot hole before driving screws

Lift the roof above the corner posts and rest it in place, the outer edges of the roof frame should sit inside the posts.

Fix the roof in place using 2 x 100mm wood screws (**FIX 3**) per corner driving through the posts from the outside.



All images are for illustration only. Please see individual item listings for actual item specifications.


Step 8

To prevent splits, drill a pilot hole before driving screws

With the roof fixed in place the fascia boards (**B4**), (**B5**) and the decorative piece (**B6**) can now be installed to finish off the roof section.

The fascia's are fastened into place using 4 x 50mm green screws (**FIX 1**) as below.

The decorative piece is to be centred on the fascia and fixed in place by screwing through the back of the frame into the piece using 1 x 50mm green screw (**FIX 1**).



With the fascias installed, you have now completed the build of the core structure.

From this point, the assembly process varies depending on the specific model you purchased.

Please Note: These instructions cover every possible configuration (Eclipse, Grillhouse, Meze, etc.), so not all upcoming steps will be relevant to you.

Please refer back to the tables on Pages 1 & 2 to confirm which specific add-ons (such as additional cladding, deluxe kits, or foldout sides) are required for your model, and follow only the steps associated with those parts.

Step 9

To prevent splits, drill a pilot hole before driving screws

To complete the base unit build, the last step is to install the side and rear capping rails (C4) and (C5). These should sit flush in-between your corner posts and are secured using 1 x 50 green screw (FIX 1) at each end, the screws should be driven through the capping rails and down into the frame uprights in the corners.

PLEASE NOTE: THESE ARE NOT TO BE INSTALLED ON ALL SHELTERS, FOR EXAMPLE, IF YOUR BBQ SHELTER HAS FOLLOUT SIDES, THE SIDE PIECES SHOULD NOT BE ADDED AS THEY STOP THE HINGES FROM BEING ABLE TO OPEN AND CLOSE PROPERLY, PLEASE REFER TO THE TABLE BELOW.



Product ID	Product Name	Side(s)	Back
52706	The Eclipse BBQ Shelter With Full Sides	0	0
52702	The Eclipse Deluxe BBQ Shelter With Full Sides	0	0
52703	The Eclipse BBQ Shelter With Single Foldout Bar Top	0	0
52722	The Eclipse Deluxe BBQ Shelter With Single Foldout Bar Top	0	0
52704	The Eclipse BBQ Shelter With Dual Foldout Bar Tops	0	0
52705	The Eclipse Deluxe BBQ Shelter With Dual Foldout Bar Tops	0	0
52719	The Grillhouse BBQ Shelter With Half Sides	2	1
52698	The Grillhouse Deluxe BBQ Shelter With Half Sides	2	1
52693	The Grillhouse BBQ Shelter With One Half / One Full Side	1	1
52694	The Grillhouse Deluxe BBQ Shelter With One Half / One Full Side	1	1
52689	The Grillhouse BBQ Shelter With Full Sides	0	1
52690	The Grillhouse Deluxe BBQ Shelter With Full Sides	0	1
52691	The Meze BBQ Shelter With Single Foldout Bar Top	0	1
52692	The Meze BBQ Shelter Deluxe With Single Foldout Bar Top	0	1
52695	The Pavilion BBQ Shelter With Single Foldout Bar Top	1	1
52696	The Pavilion Deluxe BBQ Shelter With Single Foldout Bar Top	1	1
52720	The Pavilion BBQ Shelter With Dual Foldout Bar Tops	0	1
52697	The Pavilion Deluxe BBQ Shelter With Dual Foldout Bar Tops	0	1
52701	The Vista BBQ Shelter With Full Sides	0	1
52707	The Vista Deluxe BBQ Shelter With Full Sides	0	1

All images are for illustration only. Please see individual item listings for actual item specifications.

Component List

- 1 x Decorative Chevron Panel
- 4 x 32mm Square Spindles

900mm x 960mm
900mm

(CHEV1)
(CHEV2)



Recommended Tools

- Drill Driver
- PZ2 Driver Bit
- Pilot Drill Bit
- Tape Measure
- Spirit Level

We recommend two people to assemble this BBQ shelter.

Step 1


To prevent splits, drill a pilot hole before driving screws

The final step is to fix the decorative panel (**CHEV1**) and 4 x 32mm square spindles (**CHEV2**) into position at the rear of your shelter, your panel should fit perfectly in-between the roof frame and rear capping rail.

Start by centring the panel in the gap and use 1 x 50mm green screw (**FIX 1**) to drive up through the capping rail and into the panel in the corner to fix it in place, repeat the process on the other side.

To secure the top of the panel, use 1 x 75mm green screw (**FIX 2**) to go down through the featheredge roof board, into the roof frame and into the top of the panel, again aiming for the upright in the corner.

Lastly the spindles need to be installed to complete the rear and the shelter as a whole. Following the same method as the panel, use 50mm green screws (**FIX 1**) to secure the spindles in place from the bottom and 75mm green screws (**FIX 2**) at the top. The spindles should be evenly spaced in the remaining gap.



Component List

2	x	Cladding Frame (Sides)	2" x 2" C16	830mm	(EXT1)
7	x	Cladding (Sides)	4" x 1" PAR	1200mm	(EXT2)
2	x	Cladding Frame (Rear)	2" x 2" C16	915mm	(EXT3)
7	x	Cladding (Rear)	4" x 1" PAR	1660mm	(EXT4)



Recommended Tools

Drill Driver
PZ2 Driver Bit
Pilot Drill Bit

We recommend two people to assemble this BBQ shelter.


Step 1

To prevent splits, drill a pilot hole before driving screws

Using 2 x cladding frame pieces (**EXT1**) and 7 x cladding boards (**EXT2**) assemble your side panel(s) as shown below.

The top board should fit flush with the frame piece, working down the timber with 25mm spaces in between each board, this should leave a 25mm gap at the bottom, so that when inserted on top of the existing side panel the pattern continues seamlessly.

Each board is held in place using 2x 50mm green screws (**FIX 1**) per side, per board, driven through the face of the cladding into the frame.




Step 2

Creating the back panel extension is done just the same as the side panel.

Using 2 x cladding frame pieces (**EXT3**) and 7 x cladding boards (**EXT4**) assemble your rear panel as shown below.

Each board is held in place using 2x 50mm green screws (**FIX 1**) per side, per board, driven through the face of the cladding into the frame.





All images are for illustration only. Please see individual item listings for actual item specifications.

Step 3

To prevent splits, drill a pilot hole before driving screws

Regardless of if you are installing a back or side extension panel to create a fully clad side, the installation is the same.

With the extension panel fastened together you simply lift it into place, between the posts and sit it on top of the lower panel that you fixed into place earlier when building the BBQ base unit. The fixing method is the same as step 3 of the base BBQ Unit, using 3 x 75mm green screws (**FIX 2**) one at the top, middle and bottom on each side, through the panel frame and into the side of the support posts.



All images are for illustration only. Please see individual item listings for actual item specifications.

Component List

1	x	Under Shelf Support	2" x 2" C16	1100mm	(S1)
2	x	Angled End Supports	2" x 2" C16	140mm	(S2)
1	x	Notched Shelf	6" x 1" PAR	1200mm	(S3)



Recommended Tools

- Drill Driver
- PZ2 Driver Bit
- Pilot Drill Bit
- Spirit Level

We recommend two people to assemble this BBQ shelter.

Step 1

To prevent splits, drill a pilot hole before driving screws

Begin by positioning the under shelf support **(S1)** in between the frame pieces that the side cladding is fastened to **(C1S)**, the top edges should be aligned so that they are flush with one another.

To secure this in place use 1 x 75mm Green Screw **(FIX 2)** at either end, driving through the underside of the support at an angle and into the side cladding frame.

With the support now secured in place the notched shelf **(S3)** can be placed on top with the profiled sections pushed up against the frame so it fits tightly in place, to fix it in place use 4 x 50mm Green Screws **(FIX 1)**, spaced evenly across the board, driving through the top and into the support beneath it.

The final step is to add the angled supports **(S2)** at either end, these simply attach with 1 x 50mm Green Screw **(FIX 1)** at either end going through the shelf on the top and into the support below and through the support and into the frame at the bottom.

See below diagram for reference.



All images are for illustration only. Please see individual item listings for actual item specifications.

Component List

12 x	Fold Out Side Top	4" x 1" PAR	700mm	(D1)
1 x	Fold Out Frame 1	2" x 2" C16	1090mm	(D2)
1 x	Fold Out Frame 2	2" x 2" C16	1185mm	(D3)
2 x	Side Arms Horizontal	4" x 2" C16	500mm (Angle Cut)	(D4)
2 x	Side Arms Diagonal	4" x 2" C16	635mm (Angle Cut)	(D5)
2 x	Side Arms Vertical	2" x 2" C16	600mm	(D6)
	50mm Green Screws			(FIX 1)
	75mm Green Screws			(FIX 2)
	75mm Hinges (Pairs of with Screws)			(FIX 4)
	Bar Auto Latch (inc Screws)			(FIX 6)



Recommended Tools

Drill Driver
PZ2 Driver Bit
Pilot Drill Bit
Tape Measure
Spirit Level


We recommend two people to assemble this BBQ shelter.

Step 1

To prevent splits, drill a pilot hole before driving screws


To construct the two fold out top supports, assemble pieces (D4), (D5), and (D6) as per the below diagram using 2 x 75mm green screws (FIX 2) as indicated in each corner.

Repeat the process for both supports.



With the fold out sides assembled, the 75mm hinges (FIX 4) can be fixed into position using 3 x 20mm hinge screws (FIX 5).

These need to be fitted as per below; pay attention to make sure the hinges are installed on opposing sides to one another to make sure they will be able to fold out in opposite directions once attached to the shelters frame.



All images are for illustration only. Please see individual item listings for actual item specifications.


Step 2

To prevent splits, drill a pilot hole before driving screws


To build the fold out top, lay out the supporting timbers (D2) and (D3) and arrange the top boards (D1) touching one another over the top.

These are secured in place using two 50mm green screws (FIX 1) at each end per board as indicated, with the exception of the two ends which have the shorter piece of timber as there will only be room for one screw.


The longer of the two frame timbers (D3) should sit flush on both ends whereas the shorter piece (D2) will be 50mm in from the end at both sides, see the diagrams to the right for reference.



Top View



Underside View



Step 3


To prevent splits, drill a pilot hole before driving screws

With the top built the hinges can be screwed into place, these will allow for it to be folded up and down, we recommend fixing them into position as outlined below in the middle of the second board in from either side, secured using 3 x 20mm hinge screws (**FIX 5**) per hinge.



With the hinges now attached to the top, the top can be screwed onto the shelter frame on the side of your choice.

The hinges should be positioned so that they fasten directly onto the top cladding board and sit flush with the top edge of the cladding board (see below for reference). The hinges are fixed into place using 3 x 20mm hinge screws (**FIX 5**) per hinge.



Step 4

To prevent splits, drill a pilot hole before driving screws

The two fold out top supports that you built in step 10 can now be attached to the main frame of the shelter, these will sit directly beneath the frame of the top (see below for reference).

The hinges should be positioned so that they fasten directly onto the top cladding board and the fifth board down, the fold out supports are fixed into place using 3 x 20mm hinge screws (**FIX 5**) per hinge.

The fold out supports should almost touch in the middle as per the diagram and will sit in-between the fold out top frame when opened outwards.




Step 5

To prevent splits, drill a pilot hole before driving screws


To finish the build the auto latch (**FIX 6**) needs to be fixed to the rear post and the locking bar to the underside of the fold out top, this will allow the side to be securely held in place when not folded out and in use.

To align the two parts of the latch, simply fold up the top so that it is in-between the posts, first attaching the locking bar using the provided screws to the frame of the top, with this in place it will be very easy to see exactly where on the post that the latch needs to be fixed so that the two parts interlock.



Component List

- 1 x Ecostrad XD-TS 2kw Infrared Outdoor Heater (Solaglo) - Silver (DEL1)
- 2 x Corner Braces 4" x 2" C16 (DEL2)



Recommended Tools

- Drill Driver
- PZ2 Driver Bit
- Pilot Drill Bit
- Tape Measure
- Spirit Level

We recommend two people to assemble this BBQ shelter.


Step 1

To prevent splits, drill a pilot hole before driving screws

In order to create additional strength and rigidity at the front of the frame the deluxe version upgrade supplies a set of corner braces.

The braces are secured into position using 2 x 75mm Wood Screws (**FIX2**) which are included in the base BBQ kit, one in the top into the frame and one at the bottom into the post.

Repeat this process on both front corners, as indicated in the image below.



Step 2

The heater can be installed as per your personal preference, however we have specifically picked this model as it sits nicely between the two central roof rafters as indicated on the above image.

Please see the included fitting guide, supplied with the heater for exact fitting recommendations, this details how the supplied hinges can be used to adjust the angle etc which again is at your personal preference.

A copy of installation process from these instructions are included over the next few pages for reference.


Solaglo Infrared Heater

AC 220-240V, 50/60Hz, 2000W, Class I, IP55 Rating

Kennings's

4 – 2 | Fixings

Before beginning installation, check that all fixings are supplied.



Key	Fixing	Description	Qty
1	Bracket	L-shaped	4
2	Bolt	M6mm*60mm	4
3	Screw	M5mm*10mm	4
4	Wing Nut	M6mm	2
5	Washer	Ø6mm*1mm	2
6	Screw	M6mm*12mm	2

4 – 3 | Mounting Instructions




Important – Ensure the cable is well secured so that it does not trail into the heated area or come into contact with the reflector. The cable can be fixed to the metal mounting bracket behind the heater with plastic zip ties.

The mounting bracket provided with the heater has been specifically designed to allow the product to be fitted to a wall or ceiling. Before drilling the holes for the wall or ceiling mount, please ensure that the surface is solid and that there are no hidden water pipes or electrical wires. The heater must be installed no less than 0.4m from any side walls and no less than 1.8m from the floor.

Tools Needed:

- Pencil
- Hammer
- Spirit level
- Screwdriver
- Power drill and drill bits




Solaglo Infrared Heater


AC 220-240V, 50/60Hz, 2000W, Class I, IP55 Rating

Kennings's

1. Fasten the brackets (1) together using the screws (6), washers (5) and wing nuts (4). (See Fig 1-2).




2. Line up the brackets with the wall or ceiling and mark the location of the four outer holes. Drill holes at the marked locations and fit the bolts (2) into the holes.



3. Thread the brackets over the bolts and fix securely to the mounting surface.

4. Fasten the heater securely to the brackets using the screws (3).



5. The brackets can be used to adjust the angle of the heater. Adjust the heater angle by loosening the wing nuts and tighten the bolts again when the desired angle is reached.